

Symbols

- Pressure Relief Valve
- → Balance Valve
- -b∕≨⊩ Ball Valve
- ← Check Valve
- ⊣⊩ Union
- ♦ Air Vent
- Pump
- + Flexible Fitting
- Expansion Vessel

NOTES:

- 1) NOT FOR CONSTRUCTION.
- 2) FINAL HEAT EXCHANGER MODULE DESIGN SUBJECT TO CHANGE.
- 3) PIPE FLOW VELOCITY NOT TO EXCEED 2 ft./sec.
 BIN 1/2 AEGIS UNITS WITH HEAT EXCHANGER MODULE
 MARK I.
- 4) HEAT EXCHANGER MODULE MARK I CONNECTIONS ARE 1-1/2" NPT.



Blauvelt, NY Fort Worth, TX

AEGIS A 1 UNIT INSTALLATION

DWN.BY <u>K.S.</u> DATE <u>090622</u> SCALE <u>NTS</u> APPD. _____ DATE ____

SD-L-1251

REV. A